




BY  **IRONWOOD**

CDCCR

RISER UNIT



IMPORTANT!

Assembly may require the assistance of another person.

Before you begin assembly:

READ THE DIRECTIONS all the way through one time. This will speed up the process and help you understand the sequence of steps.

COUNT THE PARTS AND HARDWARE before assembly. This ensures you have received all necessary parts before you begin.


TOOLS: You may need a Phillips head screwdriver, a medium slotted screwdriver or a plastic mallet. To protect your new furniture from damage during assembly, it is recommended to work on a carpeted surface.

In the event any parts are missing from this package, send your name, address, telephone number, and a description of the missing part(s) to: **PARTS, Box 1420, Missoula, MT 59806** or call: **1-800-769-5693** or FAX **1-800-445-5281**.


CAUTION: On assemblies requiring glue, make sure the unit is assembled correctly before gluing. Once this unit is assembled with glue, the manufacturer will not be responsible for damaged parts. Keep a damp cloth or sponge handy to wipe off excess glue.

To care for this furniture, simply wipe with a cloth dampened with glass cleaner containing ammonia-D.


PARTS DIAGRAM




Left Side	01050941	1 ea.
-----------	----------	-------



Right Side	01050941	1 ea.
------------	----------	-------



Top	01050901	1 ea.
-----	----------	-------



Right Back	01050954	1 ea.
------------	----------	-------



Left Back	01050955	1 ea.
-----------	----------	-------

HARDWARE



H1	Minifix Cam	909810	16 ea.
----	-------------	--------	--------



H2	Minifix Bolt	909834	16 ea.
----	--------------	--------	--------




H3	Dowel	195000	10 ea.
----	-------	--------	--------

Using the Minifix System:



Insert the Minifix Cam into the appropriate hole with the arrow facing outwards as shown.

Then screw bolt into **D**.
Not over tighten. Screw bolt down until bottom face of bolt flange sits to edge of door face.




Using the 2 millimeter screwdriver rotate the Cam **D** a half turn clockwise until **D**.

Remove the Cam **D** from the door panel.




#1

Insert four Minifix Cams (H1) and screw four Minifix Bolts (H2) into the Top Panel (C) as shown.




#2

Tap in four Wood Dowels (H3) and screw four Minifix Bolts (H2) into each Side Panel (A & B) as shown.




#3

Insert Minifix Cams (H1) into each Back Panel (D,E) 12 ea. as shown, making sure the arrow faces out toward the edge of the panel.




#4

Attach the Right Back (D) to the Left Back (E). Turn the Minifix Cam (H1) clockwise to tighten.




#5

Attach Back Panels to the Top Panel.




#6

Attach the Left Side (A) as shown. Turn the Minifix Cams (H1) clockwise to tighten.



#7

Attach the Right Side (B) as shown. Turn the Minifix Cams (H1) clockwise to tighten.



#8

The installation of your Glacier Corner Riser Unit is now complete and ready to use.

